

ZABAWKA – KOMPLET DERKA I NAUSZNIKI SUPER HOBBY HORSE – INSTRUKCJA UŻYTKOWANIA

Zabawka powinna być używana wyłącznie zgodnie z przeznaczeniem. Zabawka jest dostarczana gotowa do użytku, nie wymaga montażu ani złożenia.

Zabawka KOMPLET DERKA I NAUSZNIKI SUPER HOBBY HORSE przeznaczona jest do gry i zabawy w Hobby Horsing. Komplet derka i nauszniaki służy do zakładania na zabawkę Hobby Horse w celu ozdoby i dekoracji konia Hobby Horse.

INSTRUKCJA OBSŁUGI:

Wyciągnij zabawę z opakowania. Zabawka po wyjęciu nadaje się do zabawy.

Upewnij się, że dzieci korzystające z zabawki robią to pod nadzorem osoby dorosłej. Zabawkę należy trzymać z dala od ognia i wszelkich substancji łatwopalnych. Należy zwrócić uwagę aby używać zabawki wyłącznie zgodnie z instrukcją i przeznaczeniem. Należy zaprzestać użytkowania zabawki w przypadku zauważenia jakiegokolwiek uszkodzenia.

Nie wolno odrywać od zabawki żadnych wystających elementów, w szczególności elementów metalowych zapięć.

Nie wolno wkładać do ust żadnych wystających elementów, w tym elementów metalowych zapięć. Może to spowodować ryzyko urazu, zachłyśnięcia, zadławienia.

KOMPLET DERKA I NAUSZNIKI SUPER HOBBY HORSE służy wyłącznie do zakładania na zabawkę Hobby Horse, nie wolno zakładać na dziecko!

Przechowuj zabawkę w suchym i czystym miejscu. Przechowuj zabawkę z dala od dzieci w wieku poniżej 3 lat, gdyż zabawka może stanowić dla nich zagrożenie – ryzyko urazu, zachłyśnięcia lub zadławienia.

INSTRUKCJA KONSERWACJI:

Zabawka SUPER HOBBY HORSE może być prana w temperaturze 40 stopni Celsjusza przy zastosowaniu delikatnych detergentów. **Nie może być** suszona w suszarce bębnowej, czyszczona chemicznie, wybielana, chlorowana, prasowana. Nie trzeć!



OSTRZEŻENIA:

- Zabawka jest przeznaczona wyłącznie dla dzieci w wieku powyżej 3 lat.
- Z zabawki należy korzystać wyłącznie w obecności i pod nadzorem osoby dorosłej.
- Zabawka zawiera małe elementy, istnieje ryzyko połknięcia lub zakrztuszenia.
- Opakowanie zabawki nie jest przeznaczone do zabawy.
- Opakowanie foliowe zabawki – należy je usunąć bezpośrednio po rozpakowaniu zabawki aby uniknąć ryzyka uduszenia.



Esello sp. z o.o.
Ul. Fabryczna 8 , 47-208 Reńska Wieś,
Poland
NIP PL7492112109
info@esello.eu
Wyprodukowano w Polsce

SUPER HOBBY HORSE BLANKET AND EARMUFFS TOY - USER INSTRUCTIONS

The toy should only be used as intended. The toy is supplied ready to use, no assembly or mounting required. The SUPER HOBBY HORSE toy is intended for playing and enjoying Hobby Horsing - for the purpose of an additional form of exercise and fun in staging horse riding on a horse model. It is also used for practising coordination and balance. The SUPER HOBBY HORSE toy can be used for staging jumps over special obstacles, dressage and for field play.

INSTRUCTIONS FOR USE:

Take the toy out of the packaging. The toy is suitable for play.

Ensure that children using the toy do so under adult supervision. Keep the toy away from fire and any flammable substances. Take care to use the toy only in accordance with the instructions and intended use. Stop using the toy if any damage is noticed.

Do not detach any parts protruding from the toy especially metal parts.


Do not put any protruding parts - especially metal parts - into the mouth. This can cause a risk of injury, choking or choking.

The SUPER HOBBY HORSE BLANKET AND EARMUFFS TOY is only to be worn on the Hobby Horse toy, it may not be put on a child!

Store the toy in a dry and clean place. Keep the toy away from children under the age of 3, as the toy may present a hazard to them - risk of injury, swallowing or choking.

CARE INSTRUCTIONS:

SUPER HOBBY HORSE BLANKET AND EARMUFFS TOY can be washed at 40 degrees Celsius using gentle detergents. Must not be soaked, tumble dried, dry cleaned, bleached, chlorinated, ironed.



Do not rub!

WARNINGS:

- The toy is intended only for children over 3 years of age.
- The toy should only be used in the presence and under the supervision of an adult.
- The toy contains small parts, there is a risk of swallowing or choking.
- The toy packaging is not intended for play.
- Foil packaging of the toy - remove immediately after unpacking the toy to avoid risk of suffocation.



Esello sp. z o.o.
Ul. Fabryczna 8 , 47-208 Reńska Wieś, Poland
NIP PL7492112109
info@esello.eu
Made In Poland